

ROOMETTES

THE BOOKWORM #01-118-01 AND COMBO R4380

INSTRUCTIONS

1. REMOVE THE MAIN FLOOR, AS WELL AS THE FIRST FLOOR SHELVES, FROM THE CARDS TOCK SHEET WITH A SHARP HOBBY KNIFE. **DO NOT CUT THE DOTTED LINES!** THEY ARE FOR FOLDING THE ROOM.
2. CREATE THE WINDOW DISPLAY BY ROLLING THE TABS AT THE FRONT OF THE ROOM TO MAKE A WEDGE-SHAPED BOX. "GLUE OTHER SIDE" AS SHOWN ON THE TAB. A SMALL FILE OR SCREWDRIVER CAN BE USED TO APPLY PRESSURE TO THE JOINT FROM INSIDE THE BOX AS IT SETS.
3. FOLD THE WALLS OF THE ROOM TO GET A SENSE OF WHERE THE FIRST FLOOR SHELVES WILL SIT IN THE SPACE. **DO NOT OVERBEND THE WALLS!** USE YOUR KNIFE TO ROUGHEN THE SURFACE OF THE FLOOR BEHIND THE SHELVES FOR IMPROVED ADHESION. GLUE THE SHELVES IN PLACE, BEING GENEROUS WITH ADHESIVE BEHIND THEM. YOU DO NOT WANT THEM TO COME LOOSE LATER!
4. FOLD THE ROOM TOGETHER AND GLUE THE LEFT AND RIGHT WINGS UNDER THE FLOOR. USE A POPSICLE STICK OR SIMILAR TOOL TO CAREFULLY APPLY PRESSURE ON THE FLOOR OVER EACH WING TO SET THE GLUE.
5. FLIP THE ROOM OVER AND GLUE THE LEFT AND RIGHT WINGS OVER THE TOP OF THE CEILING.
6. CAREFULLY BEND UP THE TAB LABELLED "GLUE TO WALL OF BUILDING" AT A RIGHT ANGLE.
7. REMOVE THE WINDOW DISPLAY FROM THE SHEET AND GLUE IT TO THE TOP OF THE WEDGE TO FINISH THE WINDOW DRESSING.
8. ASSEMBLE THE SECOND-FLOOR ROOMS IN A SIMILAR MANNER. FOLD THE SECOND FLOOR BOOKSHELVES TO CREATE A THREE-SIDED BOX WITH 90-DEGREE TABS INSIDE AT THE TOP. APPLY GLUE TO THE TABS AND FOLD THE TOP OF THE BOOKSHELF ONTO THEM. TURN THE SHELVES OVER AND USE YOUR KNIFE TO NUDGE THE TABS TO MAKE THE SIDES SQUARE, AND THEN APPLY PRESSURE AS THE GLUE SETS. GLUE THIS ASSEMBLY INTO THE SECOND FLOOR. FINALLY, ADD THE SHELVES TO THE THIRD FLOOR ROOM. PROMOTIONAL SIGNS CAN BE "HUNG" FROM THE CEILINGS WITH GLUE.
9. CHECK ALL GLUE JOINTS TO MAKE SURE THEY ARE SOLID BEFORE PROCEEDING. TEST FIT THE ROOMS. IF YOU HAVE ASSEMBLED YOUR BUILDING ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS THEY SHOULD FIT EASILY. IF YOU FIND THEY FIT TOO TIGHT VERTICALLY YOU CAN REMOVE SOME OF THE WALL-MOUNT TAB MATERIAL WITH SCISSORS FOR ADDITIONAL CLEARANCE.
10. TO PREVENT LIGHT LEAKAGE, SPREAD A BIT OF GLUE INTO THE PERFORATED SEAMS ON THE CORNERS OF THE ROOM FROM THE OUTSIDE. THIS WILL ALSO MAKE THE JOINTS STRONGER.
11. USE YOUR KNIFE TO REMOVE THE CEILING PULLS AND INSTALL THE SUPPLIED LEDS, FASTENING THEM IN PLACE WITH GOOD QUALITY TAPE OR GLUE.
12. STARTING WITH THE UPPER FLOORS GLUE THE ROOMS TO THE WALLS, BEING CAREFUL NOT TO GET GLUE ON YOUR CLEAR WINDOW MATERIAL.
13. GLUE THE SIGN OVER THE DOORWAY ON THE FRONT OF THE BUILDING.
14. PLUG THE LED HARNESS INTO YOUR WOODLAND SCENICS® JUST PLUG® OR NCE ILLUMINATOR MODULE. SIT BACK AND ENJOY YOUR EFFORTS!

THIS IS NOT A TOY.
NOT SUITABLE FOR CHILDREN
UNDER 14 YEARS OF AGE.