ROOMETTES

MILLIE'S HOUSE #01-205-01 AND COMBO R4384

INSTRUCTIONS

- I. REMOVE THE BEDROOM FROM THE CARDSTOCK SHEET WITH A SHARP HOBBY KNIFE. **DO NOT CUT THE DOTTED LINES.** THEY ARE FOR FOLDING.
- 2. CAREFULLY BEND THE WALLS, FLOOR AND CEILING INWARD TO CREATE A BOX. **PO NOT OVERBEND THEM!**
- 3. BEND AND GLUE THE LEFT AND RIGHT WING TABS UNDER THE FLOOR. USE A POPSICLE STICK OR SIMILAR TOOL TO CAREFULLY APPLY PRESSURE ON THE FLOOR OVER EACH WING TO SET THE GLUE.
- 4. FLIP THE ROOM OVER AND GLUE THE LEFT AND RIGHT WING TABS OVER THE TOP OF THE CEILING.
- 5. BEND THE TAB LABELLED "GLUE TO WALL" AT A RIGHT ANGLE <u>OUT</u> OF THE ROOM. SET THE ROOM ASIDE TO DRY.
- 6. ASSEMBLE THE OTHER ROOM IN A SIMILAR MANNER.
- 7. CHECK ALL GLUE JOINTS TO MAKE SURE THEY ARE SOLID BEFORE PROCEEDING.
 TEST FIT THE ROOMS. IF YOU HAVE ASSEMBLED YOUR BUILDING ACCORDING TO
 THE MANUFACTURER'S INSTRUCTIONS THEY SHOULD FIT EASILY. IF YOU FIND
 THEY FIT TOO TIGHT VERTICALLY YOU CAN REMOVE SOME OF THE WALL-MOUNT
 TAB MATERIAL WITH SCISSORS FOR ADDITIONAL CLEARANCE.
- 8. TO PREVENT LIGHT LEAKAGE, SPREAD A BIT OF GLUE INTO THE PERFORATED SEAMS ON THE CORNERS OF THE ROOM FROM THE OUTSIDE. THIS WILL ALSO MAKE THE JOINTS STRONGER.
 - TIP: YOU CAN MAKE A 3-PIMENSIONAL BED FOR THE HEADBOARD BY CUTTING A DENSE STYROFOAM BLOCK AND PAINTING IT. GLUE IT TO THE FLOOR.
- 9. USE YOUR KNIFE TO REMOVE THE CEILING PLUGS AND INSTALL PROVIDED LEDS, FASTENING THEM IN PLACE WITH GOOD QUALITY TAPE AND/OR GLUE.
- 10. YOU MAY WISH TO PAINT THE INSIDE OF THE WALLS OF THE BUILDING BLACK TO PREVENT THE LIGHT FROM SHINING THROUGH THEM.
- II. GLUE THE ROOMS TO THE INSIDE WALLS OF THE BUILDING, BEING CAREFUL NOT TO GET GLUE ON YOUR CLEAR WINDOW MATERIAL.
- 12. PLUG THE LEDS INTO YOUR WOODLAND SCENICS JUST PLUG HUB, MODEL TRAIN TECHNOLOGY LSCII CONTROLLER, OR NCE ILLUMINATOR MODULE. DIM THE LEDS, SIT BACK AND ENJOY YOUR EFFORTS!

THIS IS NOT A TOY.

NOT SUITABLE FOR CHILDREN

UNDER 14 YEARS OF AGE.