



#101 Kelly's Saloon Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

Chimneys

Lightly sand bottom edge of chimney backs (101-5 & 101-6) flat. Sand or file the smooth sides of chimney backs and molded-in chimney fronts so back and front fit tight and flush with each other. Glue together. When glue is dry, sand tops of chimneys flat.

Entry Doors

Remove "tabs" (necessary for molding purposes) from tops and bottoms of entry door (101-9) and entry side panels (101-8) by cutting along the indentations with hobby knife (See Fig. 1) being careful to not damage the door frames. Note that both entry side panels have a shallow angle on one edge and a deeper angle on the other edge. Glue shallow-angled edges to entry door. While glue is still flexible on the resulting "entry assembly," glue deep-angled edges to back of columns of front wall opening. See Exploded View Drawing.

