

# ROOMETTES

## STOREFRONT ASSORTMENT #01-502-01 AND COMBO R4385

### INSTRUCTIONS

1. REMOVE THE STOREFRONT 50200 FROM THE CARDSTOCK SHEET WITH A SHARP HOBBY KNIFE. DO NOT CUT THE DOTTED LINES. THEY ARE FOR FOLDING.
2. FOLD THE ROOM TOGETHER AND GLUE THE LEFT AND RIGHT WINGS UNDER THE FLOOR. USE A POPSICLE STICK OR SIMILAR TOOL TO CAREFULLY APPLY PRESSURE ON THE FLOOR OVER EACH WING TO SET THE GLUE.
3. FLIP THE ROOM OVER AND GLUE THE LEFT AND RIGHT WINGS OVER THE TOP OF THE CEILING.
4. CAREFULLY BEND OUT THE TAB LABELLED "BEND UP & GLUE TO WALL" OUT OF THE ROOM AT A RIGHT ANGLE.
5. ASSEMBLE THE OTHER ROOMS IN A SIMILAR MANNER.
6. CHECK ALL GLUE JOINTS TO MAKE SURE THEY ARE SOLID BEFORE PROCEEDING. TEST FIT THE ROOMS. IF YOU HAVE ASSEMBLED YOUR BUILDING ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS THEY SHOULD FIT EASILY. IF YOU FIND THAT THEY FIT TOO TIGHT VERTICALLY IN THE STRUCTURES WITH MULTIPLE ROOMS, YOU CAN REMOVE SOME OF THE WALL-MOUNT TAB MATERIAL WITH SCISSORS FOR ADDITIONAL CLEARANCE.
7. TO PREVENT LIGHT LEAKAGE, SPREAD A BIT OF GLUE INTO THE PERFORATED SEAMS ON THE CORNERS OF THE ROOM FROM THE OUTSIDE. THIS WILL ALSO MAKE THE JOINTS STRONGER.  
TIP: YOU MAY WISH TO PAINT THE INSIDE OF THE WALLS OF YOUR BUILDINGS BLACK TO PREVENT THE LIGHT FROM SHINING THROUGH THE PLASTIC.
8. USE YOUR KNIFE TO REMOVE THE CEILING PLUGS AND INSTALL THE PROVIDED LEDS, FASTENING THEM IN PLACE WITH GOOD QUALITY TAPE OR GLUE.  
TIP: A SMALL DOT OF HOT GLUE ON THE CORNERS OF THE LED CIRCUIT BOARD WILL HELP TO KEEP IT IN PLACE ON THE CEILING.
9. GLUE THE ROOMS TO THE WALLS, BEING CAREFUL NOT TO GET GLUE ON YOUR CLEAR WINDOW MATERIAL.
10. ADD EXTERIOR SIGNS TO THE BUILDING AS DESIRED.
11. PLUG THE LEDS INTO YOUR WOODLAND SCENICS® JUST PLUG® HUB, MODEL TRAIN TECHNOLOGY LSCII CONTROLLER, OR NCE ILLUMINATOR MODULE. DIM THE LEDS, SIT BACK AND ENJOY YOUR EFFORTS!

THIS IS NOT A TOY.  
NOT SUITABLE FOR CHILDREN  
UNDER 14 YEARS OF AGE.